Update Method:

1.Press and hold the △ button of the controller without letting go, and plug it into the PC to enter the upgrade mode, release the △ key after entering the upgrade mode.

2.Click the "Upgrade" button to upgrade the firmware.

3.The upgrade is successful and the controller indicator light is on. Please unplug the controller.

After the upgrade, you need to manually re-calibrate the 3D joysticks and triggers:

Calibrate Method:

1.Ensure the controller is powered off.

2.Hold down **Share**  + **Options** , then plug in the USB cable. The channel indicator will flash rapidly.

3.Press the L2/R2 triggers normally 2~3 times.

4.Rotate the left and right 3D joysticks fully in all directions 2~3 cycles each.

5.Finally, long-press the ✕ button for 1 second to confirm. The channel indicator stays solid on when calibration is finished.